

Архангельск (8182)63-90-72	Калининград (4012)72-03-81	Нижний Новгород(831)429-08-12	Смоленск (4812)29-41-54
Астана +7(7172)727-132	Калуга (4842)92-23-67	Новокузнецк (3843)20-46-81	Сочи (862)225-72-31
Белгород (4722)40-23-64	Кемерово (3842)65-04-62	Новосибирск (383)227-86-73	Ставрополь (8652)20-65-13
Брянск (4832)59-03-52	Киров (8332)68-02-04	Орел (4862)44-53-42	Тверь (4822)63-31-35
Владивосток (423)249-28-31	Краснодар (861)203-40-90	Оренбург (3532)37-68-04	Томск (3822)98-41-53
Волгоград (844)278-03-48	Красноярск (391)204-63-61	Пенза (8412)22-31-16	Тула (4872)74-02-29
Вологда (8172)26-41-59	Курск (4712)77-13-04	Пермь (342)205-81-47	Тюмень (3452)66-21-18
Воронеж (473)204-51-73	Липецк (4742)52-20-81	Ростов-на-Дону (863)308-18-15	Ульяновск (8422)24-23-59
Екатеринбург (343)384-55-89	Магнитогорск (3519)55-03-13	Рязань (4912)46-61-64	Уфа (347)229-48-12
Иваново (4932)77-34-06	Москва (495)268-04-70	Самара (846)206-03-16	Челябинск (351)202-03-61
Ижевск (3412)26-03-58	Мурманск (8152)59-64-93	Санкт-Петербург (812)309-46-40	Череповец (8202)49-02-64
Казань (843)206-01-48	Набережные Челны(8552)205341	Саратов (845)249-38-78	Ярославль (4852)69-52-93

**Единый адрес для всех регионов    mtt@nt-rt.ru    <http://mettler.nt-rt.ru/>**

## Кабели

RS232C, LocalCAN, CL-5 Pin, CL-7 Pin, MiniMETTLER, DB25 и DB9.  
Соединительные кабели для различных аппаратных интерфейсов.



### Модели

Current Loop Connection Cable

GMXU-1200, RS232 to USB Connection Cable

LocalCAN "T" Cable

LocalCAN Extension Cable, 0.3m long

LocalCAN Extension Cable, 2m long

LocalCAN Extension Cable, 5m long

Relay Box, PR/SR

RS232C Connection Cable

RS232C Connection Cable

RS232C for B-S, AB-S and PB-S Option

RS25m - RS9f: connection cable for PC or RS-P42 printer, length 1m

RS9m - RS25f: connection cable for PC, length 2m

RS9m - RS9m: connection cable for devices with DB9 socket (f), length 1m