

Архангельск (8182)63-90-72
Астана +7(7172)727-132
Белгород (4722)40-23-64
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89
Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Казань (843)206-01-48

Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Липецк (4742)52-20-81
Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны(8552)205341

Нижний Новгород(831)429-08-12
Новокузнецк (3843)20-46-81
Новосибирск (383)227-86-73
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Пермь (342)205-81-47
Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78

Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Тверь (4822)63-31-35
Томск (3822)98-41-53
Тула (4872)74-02-29
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Уфа (347)229-48-12
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Ярославль (4852)69-52-93

Единый адрес для всех регионов mtt@nt-rt.ru <http://mettler.nt-rt.ru/>

Принадлежности для высокопроизводительного дозирования

Удобство и надежность



Детали и принадлежности

Принадлежности Rainin позволяют в полной мере использовать возможности Liquidator 96.

BST-96-1000-Head

BST-96-20-Head

BST-96-200-Head

LIQ-20-PA



Adapter plate

N/A

20 µl tip adapter plate stage – white

LIQ-384-PA



Adapter plate

N/A

384-well adapter plate stage

LIQ-384-PA-B



Adapter plate

N/A

384-well adapter plate stage – black

LIQ-AP



Height adjustment post

N/A

Height adjustment post for 200 μ L Liquidator 96

LIQ-AP-20



Height adjustment post

N/A

Height adjustment post for 20 μ L Liquidator 96

LIQ-MAG1



Magnetic bead separator

N/A

Magnetic bead separator plate, 24 posts, for 96 wells

LIQ-MAG2



Magnetic bead separator

N/A

Magnetic bead separator plate, 96 posts

LQR-1000

LQR-1000F

LQR-1000FLR

LQR-1000S

LQR-1000SLR

LQR-20

BioClean Liquidator 96 Tips

20 μ L maximum

960 tips in 10 racks

LQR-200

BioClean Liquidator 96 Tips

200 μ L maximum

960 tips in 10 racks

LQR-200F

BioClean Liquidator 96 Tips

200 μ L maximum

960 tips in 10 racks, filter

LQR-200S

BioClean Liquidator 96 Tips

200 μ L maximum

960 tips in 10 racks, presterilized

LQR-20F

BioClean Liquidator 96 Tips

20 μ L maximum

960 tips in 10 racks, filter

LQR-20S

BioClean Liquidator 96 Tips

20 μ L maximum

960 tips in 10 racks, presterilized

LQS-20

BioClean Liquidator 96 Tips

20 μ L maximum

960 tips in 10 layers

LQS-200

BioClean Liquidator 96 Tips

200 μ L maximum

960 tips in 10 layers

LQS-200FLR

LQS-200S

BioClean Liquidator 96 Tips

200 μ L maximum

960 tips in 10 layers, presterilized

LQS-200SLR

LQS-20FLR

LQS-20S

BioClean Liquidator 96 Tips

20 μ L maximum

960 tips in 10 layers, presterilized

LQS-20SLR

LR-P2-96-M-5



Polymeric sealing mat

N/A

Polymeric sealing mat for 96-deepwell plate, 5-pack

LR-P2-96-M-5-S



Polymeric sealing mat

N/A

Sterile polymeric sealing mat for 96-deepwell plate, 5-pack

LR-P2-96P-5



Deepwell plate

N/A

2.2 mL 96-deepwell plate, square wells, 5-pack

LR-P2-96P-5-S



Deepwell plate

N/A

Sterile 2.2 mL 96-deepwell plate, square wells, 5-pack

LR-R1-12V-5



Reusable reservoir

N/A

SBS polypropylene reusable reservoirs. Low profile 12-channel V-bottom, 5-pack.

LR-R1-12V-5-S



Reusable reservoir

N/A

SBS polypropylene reusable reservoirs. Sterile low profile 12-channel V-bottom, 5-pack.

LR-R1-8V-5



Reusable reservoir

N/A

SBS polypropylene reusable reservoirs. Low profile 8-channel V-bottom, 5-pack.

LR-R1-8V-5-S



Reusable reservoir

N/A

SBS polypropylene reusable reservoirs. Sterile low profile 8-channel V-bottom, 5-pack.

LR-R1-PB-5



Reusable reservoir

N/A

SBS polypropylene reusable reservoirs. Low profile 96 pyramidal wells, 5-pack.

LR-R1-PB-5-S



Reusable reservoir

N/A

SBS polypropylene reusable reservoirs. Sterile low profile 96 pyramidal wells, 5-pack.

LR-R2-12V-5



Reusable reservoir

N/A

SBS polypropylene reusable reservoirs. Standard profile 12-channel V-bottom, 5-pack.

LR-R2-12V-5-S



Reusable reservoir

N/A

SBS polypropylene reusable reservoirs. Sterile standard profile 12-channel V-bottom, 5-pack.

LR-R2-8V-5



Reusable reservoir

N/A

SBS polypropylene reusable reservoirs. Standard profile 8-channel V-bottom, 5-pack.

LR-R2-8V-5-S



Reusable reservoir

N/A

SBS polypropylene reusable reservoirs. Sterile standard profile 8-channel V-bottom, 5-pack.

LR-R2-PB-5



Reusable reservoir

N/A

SBS polypropylene reusable reservoirs. Standard profile 96 pyramidal wells 5-pack.

LR-R2-PB-5-S



Reusable reservoir

N/A

SBS polypropylene reusable reservoirs. Sterile standard profile 96 pyramidal wells, 5-pack.

LR-T-96-5



Microtube strips

1.2 ml

Racked 1.2 ml microtubes. 8-tube strips (8x12). Non-sterile 5-pack.

LR-T-CS8



Microtube strip caps

N/A

8-cap strips for 1.2 ml microtubes. Box of 300 strips. Non-sterile.

170

Архангельск (8182)63-90-72	Калининград (4012)72-03-81	Нижний Новгород(831)429-08-12	Смоленск (4812)29-41-54
Астана +7(7172)727-132	Калуга (4842)92-23-67	Новокузнецк (3843)20-46-81	Сочи (862)225-72-31
Белгород (4722)40-23-64	Кемерово (3842)65-04-62	Новосибирск (383)227-86-73	Ставрополь (8652)20-65-13
Брянск (4832)59-03-52	Киров (8332)68-02-04	Орел (4862)44-53-42	Тверь (4822)63-31-35
Владивосток (423)249-28-31	Краснодар (861)203-40-90	Оренбург (3532)37-68-04	Томск (3822)98-41-53
Волгоград (844)278-03-48	Красноярск (391)204-63-61	Пенза (8412)22-31-16	Тула (4872)74-02-29
Вологда (8172)26-41-59	Курск (4712)77-13-04	Пермь (342)205-81-47	Тюмень (3452)66-21-18
Воронеж (473)204-51-73	Липецк (4742)52-20-81	Ростов-на-Дону (863)308-18-15	Ульяновск (8422)24-23-59
Екатеринбург (343)384-55-89	Магнитогорск (3519)55-03-13	Рязань (4912)46-61-64	Уфа (347)229-48-12
Иваново (4932)77-34-06	Москва (495)268-04-70	Самара (846)206-03-16	Челябинск (351)202-03-61
Ижевск (3412)26-03-58	Мурманск (8152)59-64-93	Санкт-Петербург (812)309-46-40	Череповец (8202)49-02-64
Казань (843)206-01-48	Набережные Челны(8552)205341	Саратов (845)249-38-78	Ярославль (4852)69-52-93

Единый адрес для всех регионов mtt@nt-rt.ru <http://mettler.nt-rt.ru/>